

### Combination Units Secondary Glazing Section Identification


### Contents


•	Overview - Combination Examples	Page 2
•	Mullion / Transom	Page 3
•	Style 1 - Top Hung Over A Lift Out	Page 4
•	Style 2 - Lift Out Over A Top Hung	Page 5
•	Style 3 - Lift Out Over A Lift Out	Page 6
•	Style 4 - Top Hung Over A Top Hung	Page 7
•	Style 5 - Side Hung Next To A Lift Out	Page 8
•	Style 6 - Lift Out Next To A Lift Out	Page 9
•	Style 7 - Two Top Hungs Over A Lift Out	Page 10




### **Combination Examples With Recommended Sizes**

These units are supplied in one outer frame which is divided by a slim-line transom / mullion for aesthetic appeal and for prime window sight-line alignment.









Page 4


Page 5

Page 6














Page 10

2

### **Recommended Max Sizes**

Top Hung / Lift Out (Style 1)		
Max Width	1200 mm	
Max Height	2600 mm	

Lift Out / Top Hung (Style 2)	
Max Width	1200 mm
Max Height	2600 mm

Lift Out / Lift Out (Style 3)	
Max Width	1200 mm
Max Height	3000 mm

Top Hung / Top Hung (Style 4)		
Max Width	1200 mm	
Max Height	2000 mm	

Side Hung + Lift Out (Style 5)		
Max Width	1800 mm	
Max Height	1500 mm	


Lift Out + Lift Out (Style 6)	
Max Width	2400 mm
Max Height	1600 mm

2x Top Hung / Lift Out (Style 7)	
Max Width	1600 mm
Max Height	2200 mm




### **Mullion / Transom**

DG 95 Mullion / Transom (with screw ports)



DG 96 Mullion / Transom Adaptor



3



### **Style 1: Top Hung Over A Lift Out**

A C A A Lift Out Panel

### **Cross Section**

Figure 1. - Transom C

### **Economy Odd Leg System**


Section	Sight-line
А	77mm
В	77mm
С	97.5mm
D	63mm
E	52mm

Please see our Economy Odd Leg Hinged and Lift Out technical manuals for further drawings.

### **Luxury Subframe System**

Section	Sight-line
А	70mm
В	70mm
С	97.5mm
D	40mm
Е	50mm

Please see our Luxury Subframe Hinged and Lift Out technical manuals for further drawings.




E.& O.E.

4



### **Style 2: Lift Out Over A Top Hung**

5



**Cross Section** 

Figure 2. - Transom C

### **Economy Odd Leg System**


Section	Sight-line
А	63mm
В	52mm
С	97.5mm
D	77mm
E	77mm

Please see our Economy Odd Leg Hinged and Lift Out technical manuals for further drawings.

### Luxury Subframe System

Section	Sight-line
А	40mm
В	50mm
С	97.5mm
D	70mm
Е	70mm

Please see our Luxury Subframe Hinged and Lift Out technical manuals for further drawings.





**Cross Section** 

### Style 3: Lift Out Over A Lift Out

DG 95

DG 96

6

SG 64





Figure 3. - Transom C



### **Economy Odd Leg System**

Section	Sight-line
А	63mm
В	52mm
С	93mm
D	52mm

Please see our Economy Odd Leg Lift Out technical manuals for further drawings.

### **Luxury Subframe System**

Section	Sight-line
А	40mm
В	50mm
С	93mm
D	50mm

Please see our Luxury Subframe Lift Out technical manuals for further drawings.

E.& O.E.

46.5



### **Style 4: Top Hung Over A Top Hung**

7

A A A

### **Economy Odd Leg System**

Section	Sight-line
Α	77mm
В	77mm
С	102mm
D	77mm


Please see our Economy Odd Leg Hinged technical manuals for further drawings.

### **Luxury Subframe System**

Section	Sight-line
А	70mm
В	70mm
С	102mm
D	70mm


Please see our Luxury Subframe Hinged technical manuals for further drawings. **Cross Section** 

Figure 4. - Transom C





### Style 5: Side Hung Next To A Lift Out



### Plan View

### **Economy Odd Leg System**

Section	Sight-line
А	77mm
В	84.5mm
С	63mm
D	52mm

Please see our Econor.iy Cdd Leg Hinged and Lift Out technical manuals for further drawings.


### **Luxury Subframe System**

Section	Sight-line
А	70mm
В	84.5mm
С	40mm
D	50mm

Please see our Luxury Subframe Hinged and Lift Out technical manuals for further drawings.

Figure 5. - Mullion B


### Outside



8



### **Style 6: Lift Out Next To A Lift Out**



### Plan View

### **Economy Odd Leg System**

Section	Sight-line
А	63mm
В	67mm
С	52mm


Please see our Economy Odd Leg Lift Out technical manuals for further drawings.

### **Luxury Subframe System**

Section	Sight-line
А	40mm
В	67mm
С	50mm

Please see our Luxury Subframe Lift Out technical manuals for further drawings.

Figure 6. - Mullion B Outside



Inside

C

4



### Plan View

## **Economy Odd Leg System**

Sight-line	mm77	102mm	ww//	97.5mm	mm69	52mm
Section	A	В	O	D	Ш	Ш

Please see our Economy Odd Leg Hinged and Lift Out technical manuals for further drawings.

## **Luxury Subframe System**

Section	Sight-line
Α	70mm
В	102mm
O	70mm
Ω	97.5mm
Ш	40mm
Ш	50mm

Please see our Luxury Subframe Hinged and Lift Out technical manuals for further drawings.

# Figure 7. - Mullion B

Lift Out Panel

Щ.

### Outside

